

INSTRUCTIONS FOR RELIANT CORNICE

- 1. Remove hardboard top from cornice by removing screws securing top to cornice.**
- 2. Remove steel dowel pins taped to inside of cornice and place them in holes at each end and on top of display case.**
- 3. Turn cornice over exposing bottom edge of plywood panels. Unroll the ¼” foam tape, remove the backing paper and adhere it to the bottom edge of the cornice around its perimeter, forming a light seal between the cornice and the case.**
- 4. Place cornice with holes and foam light seal down over locator pins on top of case. Note that front of cornice is marked to match front of case.**
- 5. Install (2) fluorescent lamps in light fixture fastened to the hardboard top. Feed cord and plug through cord hole in hardboard top and position this now complete light assembly back onto top of cornice**

#2171 (4’ long) uses F25T8 36”

#2172-5 & #2172-6 (5’ & 6’ long) uses F32T8 48”

NOTE: IF LAMPS DO NOT LIGHT, A FIXTURE WIRE INTO A SELF-GRIPPING WIRE TERMINAL IN THE LAMP SOCKET MAY BE LOOSE. UNPLUG LIGHT, REMOVE THE FIXTURE BOX COVER, AND PUSH WIRE INTO PORCELAIN SOCKET FIRMLY TO REMEDY FAULTY CONNECTION.

INSTRUCTIONS FOR #2010, #2074, #2075, #2076, #2605 & #2606 DISPLAY CASES

FOR 2010 CASES ONLY: Remove corrugated shelf wrap from top of case containing the full length shelves for the case.

Peel or cut off wide reinforced tape holding doors in position. Remove outer door by **CENTERING**, lifting up and swinging bottom outward. Remove inner door in same manner.

Clean thoroughly the glass area to receive door handles, centering them from top to bottom on left edge of inside door and right edge of outside door. Close each door fully into frame groove. Strip paper from handle and press handle firmly onto clear glass, using the frame to align handle. To secure a good initial bond, open door and hold hand on inside face of glass behind handle pressing handle against glass with other hand.

Place the shelf brackets in the slots of the metal standards at the desired location for each shelf. Using a hammer, tap them securely into position. (NOTE: The brackets are locked in place with a wedge-action. Tapping them on the top edge close to the support standard will close a small slot appearing at the top edge where the inserted bracket meets the face of the standard, indicating they are locked in place.) Avoid placing brackets over screws in the standards. Place two shelf rests on each knife edge bracket to hold shelves; one with lip to rear, one with lip to front of bracket.

FOR 2010 CASES (full length shelves): Place shelves on the brackets with shelf rests at desired location with polished edge to the front.

FOR 2074, 2075, 2076, 2605 & 2606 CASES (half length shelves): Two half length shelves may be positioned on the common level using three brackets or one half length shelf using two brackets.

Replace doors by reversing procedure in step #1. To assure action of door lock, check level of case in its installed location. This check is accomplished by closing each door so that it is fully seated in the door track at each end of the case; the visible vertical edges of each door at the center should now be parallel. If they are not, adjust levelers under case until done.

After squaring the door frame by leveling case, lock doors. The action for this lock is a Z-bar which rises to lock and lowers to unlock. To remove the key in locked position, the doors must be tightly and squarely closed against the frame cushions in each end post taking any pressure off the Z-bar. If a door edge offers slight resistance to the Z-bar after leveling case, a modest pressure with the left hand on the door handle closing inside door and right thumb pressure closing outside door at lock point before turning key will relieve any pressure so that the key may be removed.